

Jacuzzi Instructions



On/Off Button

- ~ To activate the control panel buttons, hold the button for 2 seconds until the light turns green.
- ~ To turn off all currently active functions, hold the button for 2 seconds.



Lock/Unlock Button

- ~ The indicator light indicates the pump has a 5-minute automatic lock feature. Hold your finger on the lock/unlock button for 3 seconds to lock or unlock the pump.



Heating Button

- ~ This button is used to activate the heating system. If the light above the heating button is red, the heating system is on. If the light is green, the water has reached the set temperature, and the heating system is in standby mode.
- ~ When the heating system is activated, the filtration system starts automatically.
- ~ When the heating system is turned off, the filtration system will continue to operate.



Massage System Button

- ~ This button activates the massage system, which has a 30-minute automatic shut-off function. The light above the massage system button turns red when the system is activated.
- ~ Do not operate the massage system while the cover is on.



Temperature Adjustment Buttons



- ~ Pressing the temperature increase or decrease button causes the LED to flash. During flashing, the desired temperature can be set. The new and desired temperature setting will remain displayed for 3 seconds to confirm.
- ~ The default temperature is 35°C.
- ~ The adjustable temperature range is between 20°C and 40°C.



Water Filter Button

- ~ This button turns the filter pump on or off.
- ~ The light above the water filter button turns red when the system is activated.